

HOW TO OPERATE

1. Slide and remove battery lid. Install two CR2032 batteries matching correct (+) or (-) poles as shown. Slide lid back into place.
2. Switch unit on. Green light should appear on LED. If LED lights red, remove and replace batteries.
3. When a wireless camera is discovered, LED will flash green and audio alarm will sound.



NOTE

Do not bend or attach key chains or other items to unit.

This unit detects radio signals from wireless cameras only. **It cannot detect the presence of CCTV cameras or microphones.**

Remove batteries when unit will not be used for extended periods of time.

Avoid placing unit in extreme temperatures. Do not get wet or drop.

© 2008

Specifications subject to change without notice. Made in Taiwan